

10. Incorrect. The answer is false not true. Upon reaching the destination port, LNG is transferred from the ships to tanks at the coastal terminal and subsequently is regasified by warming up the liquefied natural gas utilizing specially built heat exchangers. After this it is put into the gas grid and delivered to users.